

	FREQUENZA	SW1	1	2	3	4	5	6
0	1Khz Test		ON	ON	ON	ON	ON	ON
1	67.0		ON	ON	ON	ON	ON	OFF
2	69.4		ON	ON	ON	ON	OFF	ON
3	71.9		ON	ON	ON	ON	OFF	OFF
4	74.4		ON	ON	ON	OFF	ON	ON
5	77.0		ON	ON	ON	OFF	ON	OFF
6	79.7		ON	ON	ON	OFF	OFF	ON
7	82.5		ON	ON	ON	OFF	OFF	OFF
8	85.4		ON	ON	OFF	ON	ON	ON
9	88.5		ON	ON	OFF	ON	ON	OFF
10	91.5		ON	ON	OFF	ON	OFF	ON
11	94.8		ON	ON	OFF	ON	OFF	OFF
12	97.4		ON	ON	OFF	OFF	ON	ON
13	100.0		ON	ON	OFF	OFF	ON	OFF
14	103.5		ON	ON	OFF	OFF	OFF	ON
15	107.2		ON	ON	OFF	OFF	OFF	OFF
16	110.9		ON	OFF	ON	ON	ON	ON
17	114.8		ON	OFF	ON	ON	ON	OFF
18	118.8		ON	OFF	ON	ON	OFF	ON
19	123.0		ON	OFF	ON	ON	OFF	OFF
20	127.3		ON	OFF	ON	OFF	ON	ON
21	131.8		ON	OFF	ON	OFF	ON	OFF
22	136.5		ON	OFF	ON	OFF	OFF	ON
23	141.3		ON	OFF	ON	OFF	OFF	OFF
24	146.2		ON	OFF	OFF	ON	ON	ON
25	151.4		ON	OFF	OFF	ON	ON	OFF
26	156.7		ON	OFF	OFF	ON	OFF	ON
27	159.8 *		ON	OFF	OFF	ON	OFF	OFF
28	162.2		ON	OFF	OFF	OFF	ON	ON
29	165.5 *		ON	OFF	OFF	OFF	ON	OFF
30	167.9		ON	OFF	OFF	OFF	OFF	ON
31	171.3 *		ON	OFF	OFF	OFF	OFF	OFF
32	173.8		OFF	ON	ON	ON	ON	ON
33	177.3 *		OFF	ON	ON	ON	ON	OFF
34	179.9		OFF	ON	ON	ON	OFF	ON
35	183.5 *		OFF	ON	ON	ON	OFF	OFF
36	186.2		OFF	ON	ON	OFF	ON	ON
37	189.9 *		OFF	ON	ON	OFF	ON	OFF
38	192.8		OFF	ON	ON	OFF	OFF	ON
39	196.6 *		OFF	ON	ON	OFF	OFF	OFF
40	199.5 *		OFF	ON	OFF	ON	ON	ON
41	203.5		OFF	ON	OFF	ON	ON	OFF
42	206.5 *		OFF	ON	OFF	ON	OFF	ON
43	210.7		OFF	ON	OFF	ON	OFF	OFF
44	218.1		OFF	ON	OFF	OFF	ON	ON
45	225.7		OFF	ON	OFF	OFF	ON	OFF
46	229.1 *		OFF	ON	OFF	OFF	OFF	ON
47	233.6		OFF	ON	OFF	OFF	OFF	OFF
48	241.8		OFF	OFF	ON	ON	ON	ON
49	250.3		OFF	OFF	ON	ON	ON	OFF

50	254.1 *	OFF	OFF	ON	ON	OFF	ON
51	255 *	OFF	OFF	ON	ON	OFF	OFF
"*" Tono fuori standard							